



LEGEND

- ① HUNTER ECO-ID-12: NOZZLE AND CAP PER PLAN
- ② FINISHED GRADE
- ③ ADJACENT MULCH
- ④ LATERAL PIPE PER PLAN
- ⑤ LATERAL FITTING PER PLAN
- ⑥ HUNTER SWING JOINT (PER PLAN)

NOTE: CHECK VALVE INOPERABLE WHEN USING SIDE INLET

**ECO-INDICATOR (ECO-ID-12)
WITH HUNTER SWING JOINT**

00

N.T.S.